



smartris Servo Drive



<Note>

- This product should be handled by only those who have been trained for the work.
Please read this manual carefully before use.
- Deliver this manual to the customer who will actually use the product.
- This instruction manual should be carefully stored.

Introduction: Safety Precautions


- Carefully read this maintenance manual and all accompanying documents before use (installation, operation, maintenance, inspection, etc.). Please use this product after thoroughly understanding the machine, information about safety, and all precautions for correct operation.
After reading, retain this manual for future reference.
- Pay close attention to the "DANGER" and "CAUTION" warnings regarding safety and proper use.



Improper handling may result in physical damage, serious personal injury and / or death.



Improper handling may result in physical damage and/ or personal injury.

Matters described in  may lead to serious danger depending on the situation.
Be sure to observe important matters described herein.



- Transport, installation, wiring, operation, maintenance, and inspections should be performed by trained technicians; otherwise, electric shock, injury, fire, or damage to the equipment may result.
- When the unit is to be used for the personnel transport vehicle, install a safety protecting device on the elevator side to prevent it from falling; otherwise, personal injury or damage to the equipment due to falling of hoisting equipment.

Introduction: How to Refer to the Maintenance Manual, Table of Contents

This is the maintenance manual for the smartris servo drive unit.

For handling of motor and gear units, see the smartris Gearmotor Maintenance Manual (No. DM1801E).

Contents

Introduction: Safety Precautions	1
Introduction: Reading the Maintenance Manual, Table of Contents	2
1. Overview	4
1-1 Purpose of This Document	4
1-1 Safety Precautions	4
1-3 Warranty	6
1-4 Power Source Specifications	6
1-5 Installation and Terminal Connections	7
1-6 Ambient Conditions	11
1-7 Certification	11
1-8 Motor and Circuit Protection	12
1-9 Startup	13
1-10 Location of Installation	13
1-11 Maintenance	13
2. Dimensions	14
2-1 Dimensions	14
2-2 Installation	15
2-3 Wiring Precautions	15
2-4 Power Adapters and Supplied Voltage	15
3. Technical Data	16
3-1 Power Cables	16
4. Operation Mode Functions	17
4-1 Analog Mode	17
4-2 CANOpen Mode	18
4-3 Motor Brake	19
4-4 Digital I/O	22
5. STO Safety Function (Optional)	25
5-1 STO (Safe Torque Off)	25
5-2 Hardware Specifications	25
5-3 Software Specifications	26

Introduction: How to Refer to the Maintenance Manual, Table of Contents

- 5-4 Safe Operation Sequence Procedures 27
- 5-5 Example of Schematic Application 27
- 5-6 Function Check 27
- 6. CANOpen Communication 28
 - 6-1 CANOpen Network Topology 28
 - 6-2 CANOpen Btrrate and Node ID 28
 - 6-3 CANOpen Overview 29
 - 6-4 DSP402 State Machine..... 36
 - 6-5 CANOpen Run Sequence 37
 - 6-6 Speed Polarity 39
 - 6-7 Store and Restore 39
- 7. Measurement Unit Conversion 42
 - 7-1 Conversion Parameters for Measurement Unit 43
- 8. Diagnostic 45
 - 8-1 Diagnostic 45
- 9. Connections 47
 - 9-1 Connection Diagram 47
 - 9-2 Nameplate and Codes 48
- 10. Cables (Optional) 49
- 11. Warranty 51

1. Overview

1-1 Purpose of This Document

This document describes the safe installation and operation of this product.

Please read it before using, and follow all safety warnings and cautions herein to ensure safe handling of this product.

Keep this document in a location where you can use it at any time.

CAUTION

- This document is a maintenance manual for qualified persons who will use this product.

Only qualified persons should transport, wire, install, and operate this motor.

The contents of this document are subject to change without notice as a result of product improvements, etc.

1-2 Safety Precautions

Follow the safety procedures described in this document to ensure safe operation.

When operating this product and its peripheral devices, It is required to protect its operators and the surrounding area.

CAUTION

- It is necessary to confirm that all system switches are working properly and that there are no warning indicators.
- Before startup, check wiring and confirm that there is no damage to the drive unit.
- Applying voltages other than those specified or reversed cable connections may cause faults in the drive unit.
- Do not connect or disconnect cables while the power is on or during operation.
- Operators are responsible for performing safe installations in compliance with any applicable laws and standards.

Notes: 1. Thoroughly read this document before performing installation.

This product contains parts that are sensitive to static electricity; improper handling may result in faults. To prevent electrostatic faults, avoid contact with highly insulating plastic films and synthetic fibers.

Place this product on a conductive material and ground it to discharge static electricity.

Keep covers and control panels closed to avoid worker injury and product faults.

1. Overview

DANGER

- Never connect or disconnect drive unit wiring when the power is ON; otherwise, faults or electrocution due to arcing discharge may occur.
 - High voltage is applied to cables even when the motor is stopped. Never remove any cables.
 - When disconnecting power connections after turning the power off, wait at least one minute before touching the device, because capacitors and contacts will remain charged.
- We recommend using an instrument to measure voltage before touching the device.

DANGER

- The drive unit surface can become dangerously hot.
- Note that the heat sink and cables can also reach high temperatures.

CAUTION

- The following are cautions for avoiding personal injury and faults in the product and other devices.
- Only apply DC power within the voltage specifications listed in this document.
 - When connecting power cables to this product, isolate it from dangerous high-voltage lines and use insulation that complies with safety standards.
 - Before operating this product, ensure it was installed according to the procedures in this manual.
 - Confirm proper operation before using the Safe Torque Off function.
 - If the device catches fire, never throw water directly on it to extinguish it.

CAUTION

- This is information for confirmation to ensure normal operation and understanding of the product.

Safety checks must be performed for workers and devices according to the appropriate standards.

1. Overview

1-3 Warranty

This manual presents information that is guaranteed to prevent accidents due to faults or wiring tasks for this product.

Strictly adhere to the specifications described in this document and catalogs.

- Do not remove the cover from the main unit.
- Do not remove any warning labels.
- Modifications to the drive unit or its parts will void the warranty.

Also, faults due to failure to perform actions described in this Maintenance Manual will void the warranty.

See "11. Warranty" for details regarding the product warranty.

1-4 Power Source Specifications

Table 1-1 Power Source Specifications

Item	Description
Power supply voltage	48 Vdc (30 - 60 Vdc)
STO power supply voltage	24 Vdc (20 - 28 Vdc)

Note: Never connect power supplies with voltages exceeding specifications.

Supplying high voltage to the drive unit may result in faults in its internal parts.

1-5 Installation and Terminal Connections




Fig. 1-1 External Appearance of the smartris Servo Drive Unit

Table 1-2 Power Connections

Pin No.	Signal	Description
+	+VBUS	Connection to +VBUS (+48 Vdc)
—	-VBUS	Connection to -VBUS

Table 1-3 Motor Connections

Pin No.	Signal	Description
U	phase U	Motor phase U
V	phase V	Motor phase V
W	phase W	Motor phase W

Note: See “3-1 Power Cables” regarding recommended cables.
Terminal: M6 screw, 7 N·m tightening torque



Table 1-4 Brake Connections

Pin No.	Signal	Description
+	+VBUS	“Brake+” and +VBUS connection
B	BRAKE	“Brake” and B connection

Note: Cable with 1 mm²-AWG19 or higher is recommended

1. Overview

■ X1 Connector Connections (Control Signals)



Note: See "10. Cables (Optional)" regarding cables.

Table 1-5 X1 Connector Control Signals

Pin No.	Signal	Description	Color
1	0V24	GND (control board power)	Black
2	COMMON	Digital input common	Pink
3	IN1	Digital input 1	White/pink
4	IN2	Digital input 2	Yellow/pink
5	IN3	Digital input 3	Pink/green
6	IN4	Digital input 4	Pink/brown
7	TX/485+	TX232 signal/485+ signal	Gray/brown
8	RX/485 -	RX232 signal/485 - signal	Gray/green
9	485_T	120 Ω terminal resistor 485 (connected to 485+)	White/gray
10	GND_COM	GND (RS232 serial communication)	Gray
11	RET1	Safety relay 1 (output)	White/red
12	STO1	Safety relay STO1 (input)	Yellow/red
13	GND_REF	GND (analog command)	Brown/green
14	REF-	Analog input -	Brown
15	REF+	Analog input +	Yellow
16	+10V	10 Vdc output	Purple
17	OUTDAC	Analog output	White/yellow
18	GND_DAC	GND (analog output)	White/black
19	GND_CAN	GND (CAN)	Brown/black
20	CAN_T	120 Ω terminal resistor CAN (connected to CAN H)	White/green
21	NC	-	-
22	COM_RET	Common (RET1/RET2: output)	Yellow/brown
23	STO2	Safety relay STO2 (input)	Yellow/brown
24	24/48V	Switching power	Red
25	V_OUT	Digital output common	Blue
26	OUT1	Digital input 1: DRIVE OK	White/blue
27	OUT2	Digital output 2: Open collector	Gray/blue
28	OUT3	Digital output 3: Open collector	Green/blue
29	OUT4	Digital output 4: Brake commands Note 1	Yellow/blue
30	CAN_L	CAN_L connection	Green
31	CAN_H	CAN_H connection	White
32/33	NC	-	-
34	RET2	Safety relay 2 (output)	Green/red
35	STO_COM	Common (STO1/STO2: input)	Yellow/black

Notes: 1. Enabled when the brake is connected.

2. Digital input 24 V ± 20%, digital output 24 V ± 20%, impedance 3 kΩ, 7 mA

■ X2 Connector Connections (for Feedback)





Table 1-6 X2 Connector, Feedback Signals

Pin No.	Resolver	Absolute encoder
1	S2 (SIN+)	SIN
6	S4 (SIN-)	REFSIN
2	S1 (COS+)	COS
7	S3 (COS-)	REFCOS
3	R1 (REF+)	DATA+
8	R2 (REF-)	DATA-
10	-	+8V
11	-	GND
4	-	-
9	-	-
14	-	-
5	SCH	SCH
12	NTC1a	NTC1a
13	NTC1b	NTC1b

Note: See “10. Cables (Optional)” regarding cables.

DANGER

The following are precautions for avoiding injury and risk of death due to improper use.

■ Avoid ground loops in wiring for control devices.

- When connecting the PC, the encoder, switches, actuators, etc., to the control connector, never connect ground (pins 1, 10, 13, 18, 19) and battery negative (-) terminals.

Never disconnect the battery negative (-) terminal while the battery positive (+) terminal is connected to the drive unit. Excess current flows from the ground pin, so disconnecting a wire or connector can result in damage or faults to controllers and peripherals.

- The controller connector grounds (pins 1, 10, 13, 18, 19) are connected to drive unit by internal negative (-) terminals.

- Be sure to connect battery negative (-) terminals in controller ground wiring.

- Do not use power ground cables for connectors and switches.

- Shield external I/O signals to prevent effects from main power.

1. Overview

■ Connection Example




Fig. 1-2 Connection Example for Drive Unit and Controller

1-6 Ambient Conditions

This product must be installed in appropriate ambient conditions to ensure safe operation. Faults due to modifications or inappropriate storage conditions will void the product warranty. Keep the device covered for protection from dust, metal filings, water, oil, etc.

Item	Details
Ambient temperature	-10 °C - 40 °C
IEC60068-2-2	40–55 °C: Requires motor capacity derating
Ambient humidity	≤85% RH, no condensation
Altitude	Altitude: 1000 m max.
Protection class	IP54
Contamination level	2(EN 2, 61800, EN61800-5-1)

CAUTION

This product diffuses heat by heat dissipation and conduction. The maximum allowable ambient temperature is 55 °C; this product cannot be used in environments with higher temperatures.

Storage	Details
Storage temperature	-10 °C - 70 °C
Storage humidity	≤90% RH, no condensation

1-7 Certification

(1) CE Compliance

This product is certified for the conformance with the following EC Directives by Certification Bodies.

- EMC Directive (2014/30/EU)
- RoHS Directive (2011/65/EU)
- WEEE Directive (2012/19/UE)

(2) Safety

This product is compliant with the following EN safety standards:

- **EN 61800-5-1**: Adjustable speed electrical power drive systems - Part 5-1: Safety requirements – Electrical, thermal and energy.

(3) EMC Requirements

This product satisfies category requirements for emission and immunity conditions for “type-2 environments” (industrial environments).

- **EN 61800-3**: Adjustable speed electrical power drive systems - Part 3: EMC requirements and specific test methods.

1. Overview

(4) Safety Conformity (STO)

This product is equipped with two-channel Safe Torque Off (STO) input compliant with safety functions. (Optional)

This function halts PWM output and safely stops torque of the drive unit.

The circuit designs have been tested and certified by TÜV SÜD.

The STO safety function for circuit designs in this product are compliant with the following EN standards:

- **EN61508**: Functional safety of electrical/electronic/programmable electronic safety-related systems
- **EN61800-5-2** and category: Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional
- **EN ISO 13849-1:2015**: Safety of machinery — Safety-related parts of control systems — Part 1: General principles for design.

Subsystems include safety conditions with the following characteristics:

EN 13849-1	EN 61508	PFHD [1/h]
PLe	SIL3	-

(5) Ambient Conditions for Vibration and Shock

The drive unit satisfies the following specifications:

- Vibration: DIN EN 60068-2-6:2008
- Vibration frequency range: 10–150 Hz
- Acceleration: 5G

1-8 Motor and Circuit Protection

There is no need for connecting a thermal relay for motor protection. Overload protection is possible with the I²t function (electronic thermal).

Protection function parameters are as follows:

- Nominal current
- Peak current
- Overload

Nominal current and peak current are motor characteristics. The overload time is the initial value due to the load and motor, but can be set programmatically.

Drive behavior after the overload time has elapsed can be set as follows:

- Occurrence of overload alarms
- Operation under peak nominal current

The motor's temperature sensor has a function for protecting the motor from overheating.

In that case, drive operation can be set as follows:

- Even with the sensor detecting temperatures above the threshold, continue operation until the motor overheat alarm.
- It is possible to read sensor temperature values and reduce the load or speed to lower the motor temperature.

1-9 Startup

EMC directives forbid startup before confirmation that this product was installed in compliance with EC Directive standards.

Also, standards for machinery directives (2006/42/EC) and EMC directives (2014/30/EU) prohibit application and operation of this product with incompatible mechanical systems.

Machine and system manufacturers must ensure EMC thresholds satisfying the requirements of EMC standards.

(1) Proper Usage

This product can be applied to drive synchronous servo motors using permanent magnets (servo motors compatible with machine and system feedback systems).

This product is certified for use in industrial applications. Note that its use in residential areas requires additional EMC countermeasures.

The customer will need to prepare a risk analysis for the final product.

CAUTION

- Customers planning use for nonindustrial applications must first obtain our approval.

(2) Inappropriate Uses

This product is incompatible with motors other than synchronous servo motors. It also cannot be used in motors incompatible with feedback systems.

Note that installation in areas presenting the danger of flammable materials, flammable gases, dust, etc., can result in fire or explosion.

Do not install the drive unit or gearmotor of this product in such environments.

1-10 Location of Installation

Install this Protection Standard IP54 product in a place where it can operate reliably.

It must be installed in a location conforming to IP54 class or higher protective structures.


1-11 Maintenance

Perform periodic maintenance and inspections to ensure that the drive unit is free of abnormal appearances, dust adhesion, and loose connectors or terminals.

Disassembling this product will void its warranty. When disassembling, safety functions corresponding to standards are not guaranteed.

2. Dimensions

2-1 Dimensions



Unit: mm Mass: 1.6kg

2. Dimensions

2-2 Installation

Safety Precautions

- Install the drive unit inside a control panel to prevent humidity, water droplets, and metal dust.
- Before installation, confirm that the drive unit is not damaged.
- Ensure sufficient ventilation within the control panel.
- Do not operate the drive unit if condensation generates.

2-3 Wiring Precautions

Safety Precautions

CAUTION

- Ensure that the system is displaying no alarms to confirm safety.
- Before operation, check that the wiring with the drive unit is correct and these cables have no damage.
Before operation, confirm there are no problems with the drive unit and wiring.
- Non-specification voltages, reversed polarity of connections, improper wiring, etc., can result in drive unit faults or damage.
- Improper protection against excess power can result in damage to the drive unit or wiring.
- See "5. STO Safety Function (Optional)."

2-4 Power Adapters and Supplied Voltage

24V for STO logic and 48Vdc power supply must supply constant voltage.

CAUTION

- Using power adapters that do not conform to SELV/PELV designs can produce dangerously high voltages that may result in injury or death.

48 Vdc power adapters must allow regeneration up to 60 Vdc during motor regeneration operation. Power adapters must be designed to accommodate the above regeneration operation.

3. Technical Data

3-1 Power Cables

The table below shows an example of cable size selection for wiring to the servo motor and power supply.

Table 3-1 Example of Power Cable Selection

AGV load (kg)	Motor output (W)	Power source cable (mm ²) - AWG	Protective fuse (A)
600	430	2.5 - AWG14	25
1000	600	4 - AWG12	50
1500	1000		
1500	1000	6 - AWG10	100
2500	1500		

Note: Power supply voltage is 48 Vdc (max. 60 Vdc)

Cables in the table are reference examples. Applicable to Lafert or similar servo motors.

- This document is applicable to the following feedback.
 - Resolver
 - Absolute encoder

4. Operation Mode Functions

⚠ CAUTION

- This product optionally includes a Safe Torque Off (STO) safety feature. Please confirm correct operation of circuits for this function before operation. See "5. STO Safety Function (Optional)" for details.

4-1 Analog Mode

This product can be operated with $\pm 10\text{ V}$ speed commands.

Voltage inputs for speed commands are REF+ and REF-. (See Fig. 4-1 and Table 4-1 for X1 connector control signals.)

The servo motor speed can be changed to the maximum speed by following the voltage between REF+ and REF-.

Speed commands are proportional to input voltage from -10 V to $+10\text{ V}$.

$+10\text{ V}$: maximum speed during forward rotation; -10 V : maximum speed during reverse rotation

■ Speed Commands (For Servo motor Maximum Speed of 3000 r/min)

Input voltage = $+10\text{ V}$ → $+3000\text{ r/min}$
= $+5\text{ V}$ → $+1500\text{ r/min}$
= -10 V → -3000 r/min
= -5 V → -1500 r/min




Fig. 4-1 X1 Connector











Table 4-1 X1 Connector Control Signals

Pin No.	Signal	Description
3	IN1	Digital input 1: RUN command Note
4	IN2	Digital input 2: STOP command Note
5	IN3	Digital input 3: Dynamic brake command (see "4.5 Motor Brake")
6	IN4	Digital input 4
13	GND	GND (analog input)
14	REF-	Analog input -
15	REF+	Analog input +
16	+10V	10 Vdc output

Note: Setting IN1, IN2 to ON operates the servo motor.

4. Operation Mode Functions

Table 4-2 Analog Mode LED Display

IN1	IN2	Drive State	Status 1 Green LED	Status 2 Yellow LED	LED Display
OFF	X	STAND-BY	"Blink"	OFF	 1 Blink, 50%  2 OFF
X	X	FAULT See "8. Diagnostic"	"Blink" Code [x]	"Blink" Code [y]	 1 Code  2 8. Diagnostic, Table 8-2
ON	ON	RUN	ON	OFF	 1 ON  2 OFF
ON	OFF	STOP	ON	ON	 1 ON  2 ON
X	X	Safety STO OFF See "5. STO Safety Function (Op- tional)."	OFF	"Blink"	 1 OFF  2 Blink, 50%

IN3 is programmable input for dynamic brake (emergency stop).

Enabled/disabled for dynamic brake can be logically selected.

- (1) IN3: ON → OFF Dynamic brake enabled
- (2) IN3: OFF → ON Dynamic brake disabled

(1) Monitoring

Analog mode allows connection to the CAN interface and monitoring the following items that change during drive by CANOpen.

- Object 2002h: Drive status mode
- Object 2003h: Warning
- Object 2004h: Servo drive state
- Object 2030h: Drive unit temperature
- Object 2031h: Motor temperature
- Object 2032h: Heat sink temperature
- Object 2041h: Bus voltage
- Object 2050h: Torque current
- Object 2051h: Drive power
- Object 2052h: Motor power
- Object 2053h: Velocity filtered
- Object 3020h: Digital input
- Object 3022h: Analog input
- Object 4000h: Safety state

4-2 CANOpen Mode

The open network CANOpen (DS301-DS402) can be used with this product.

See "6. CANOpen communication" and the smartris CANOpen Communication User's Manual (No. DM1803E).

4. Operation Mode Functions

4-3 Motor Brake

Motor brake operates by being supplied power.


The DIG-OUT4 (digital output 4) signal operates the brake relay.

(The relay requires external power.)

Enabling this function requires setting the BIT_BRAKE customer flag (second flag from the top).

The brake can be set to automatic or manual.

- Automatic mode: Inputting the RUN/Enable operation command allows automatic brake release.
Brake power (+24 V)
- Manual mode: The brake release command can be issued by CANOpen communication or a parameter.



■ Automatic Mode




Fig. 4-2 Automatic Brake Operation

4. Operation Mode Functions

Manual Mode

In CANopen mode, set bit 1 of 60FEh (subindex 1).

- Set brake [60FEh (subindex 1), bit 0] = 1 for brake release.

(1) Standby to Operation Phase (STBY → RUN)

In STBY, the brake is released and the motor is locked.

During the time set by Delay 1, the motor is in the stop status even if the RUN signal is input.

Even after the Delay 1 time elapses and the brake is released, the motor remains stopped for the time set by Delay 2.

After the Delay 2 time, RUN mode starts and the motor reaches the set speed.

Even when the motor is stopped, stall torque (retention torque) is generated.

Note: Brake delay time is the time from issuance of the brake release command to motor lock release.




Fig. 4-3 Automatic Brake Delay Time

4. Operation Mode Functions

(2) Phases from Operation to Standby (RUN → STBY)

In the RUN state, the brake is released. When halting, stop operation differs according to whether dynamic brake is enabled, as shown in the figure below.




Fig. 4-4 Dynamic Brake

When the dynamic brake function is OFF, as in the first case in Fig. 4-4, the motor decelerates at the free run speed.

The brake locks the motor when the speed reaches zero, or when the deceleration time exceeds the set brake timeout time.

When the dynamic brake function is ON, deceleration occurs in the ramp time set in the dynamic brake parameters.

After ramp deceleration completes, the brake's locking the motor, and the motor's stopping with the delay time set in the dynamic brake parameters, the drive unit turns to be STBY mode.

4. Operation Mode Functions

4-4 Digital I/O

The following digital I/O are available.

- Digital input 4: **DIG-INx**
- Digital input 4: **DIG-OUTx**
- Safety digital input 2: **DIG- STO**

(1) Digital Input

This is an analog mode for operating the motor by using two digital inputs.

- **DIG-IN1** = RUN (analog mode)
- **DIG-IN2** = STOP (analog mode)

Drive unit with the STO function can utilize STO safety.

When the drive unit is in the safety state, STO is enabled regardless of other functions.

In the case of a drive unit being out of order (fault), the drive unit transfers to the FAULT state.

When the "Enable CAN" flag is set, the state machine follows the controlword (6060h) and digital input is ignored.

DIG-IN3 can be programmed as "**Enable Input Emergency**."

In this case, DIG-IN3 is used for transition from RUN to STANDBY in an emergency with dynamic brake.

This function is enabled through the following settings:

- CANOpen: Set object 0x3008h (Emergency Input Enable) subindex 1.

Logic for dynamic brake input (DIG-IN3) can be selected.

- CANOpen: Set object 0x3008h (Emergency Input Enable) subindex 2.

DIG-IN4 resets the drive unit hardware.

4. Operation Mode Functions




Fig. 4-5 Analog Mode State Machine

4. Operation Mode Functions

(2) Digital Input, Safety STO

DIG-STO: STO input is shown in the following circuits.




Fig. 4-6 STO Output Feedback Relay

If the application requires deceleration and stop (controlled deceleration and stop) before use of the STO function, first perform deceleration and stop operation, then activate the STO function after stop.

1. Drive deceleration and stop operation
2. In the case of stop state, disable the drive unit.
3. If there is a suspended load, mechanically lock the drive as well.
4. Activate the STO function.

CAUTION

The drive unit cannot generate torque when the STO function operates, so load cannot be maintained.

- When the STO function is operated during driving, the drive unit stops without control.
- If the drive unit has an STO function, it is necessary to confirm that all circuits for the drive unit are correct in addition to function settings for it.

■ STO 2 Input Feedback

Feedback signals for each STO input can be monitored by two-channel relay output (RET1, RET2).

The status of STO commands can be monitored by output from each relay. (Safety functions can be completely monitored.)

The state of digital input can be read with CANOpen DSP402 (60FDh: Sub-Index 0)

(3) Digital Output

DIG-OUT1: Indicates the drive state.

- 1 = Drive OK
- 0 = Drive fault

DIG-OUT2, DIG-OUT3: Can be used as general-purpose output.

DIG-OUT4: Indicates the brake status.

- 1 = Brake release, motor shaft free.
- 0 = Brake operation, motor lock

CANOpen DSP402: 0x60FE can be read with the status of digital output.

5. STO Safety Function (Optional)

Safety circuits include safety functions based on IEC 61800-5-2.

The STO module conforms to uncontrolled stop in "Stop category 0: IEC 60204-1," shutting off torque output.

5-1 STO (Safe Torque Off)

In the STO state, power for the motor to generate torque is not supplied.

The motor therefore cannot rotate.

Notes: 1. This safety function is compatible with uncontrolled stop.

2. Use this function when required to shut off output to prevent unexpected start-up.

3. In the presence of external influences (falling due to suspended load, etc.), it is necessary to use an additional measures (a mechanical brake, etc.) to prevent danger.

(1) STO Connections




Table 5-1 I/O signals (AGV)

Pin No.	Signal	Description
11	RET1	Safety relay 1 (output)
12	STO1	Safety relay STO1 (input)
22	COM_RET	Common (RET1/RET2: output)
23	STO2	Safety relay STO2 (input)
34	RET2	Safety relay 2 (output)
35	STO_COM	Common (STO1/STO2: input)

5-2 Hardware Specifications

- STO input: STO1, STO2 (common: STO_COM)
- Relay output: RET1, RET2 (common: COM_RET)

Table 5-2 STO Input Specifications

STO Input	Data
STO Inactive status (normal operation) input voltage	20 - 28 Vdc
STO Active (SAFETY) input voltage	< 2.4 Vdc
Input current	29 mA
Active response time (time from normal to STO operation)	10 ms
RET1, RET2 connection specifications (rated voltage/current)	30 V/0.5 A

5. STO Safety Function (Optional)

Table 5-3 I/O Relay Operation

Input 1	Input 2	Output 1	Output 2	Output Status
STO1	STO2	RET1	RET2	Status
0 V	0 V	Closed	Closed	Safety
24V		Open		
0V	24V	Closed	Open	Normal mode
24V		Open		

■ If either STO1 or STO2 is 0 V, safety mode (zero torque) operates.




Fig. 5-1 STO Output Relay

5-3 Software Specifications

Safety procedure: RUN → STANDBY → SAFETY

Recovering from SAFETY to STANDBY mode requires setting STO and RUN to reactive.

The recovery procedure is as follows.

- In analog mode: SAFETY → STANDBY → RUN
- In CANOpen mode: SAFETY → SWITCH ON DISABLED
→ READY TO SWITCH ON → SWITCH ON
→ OPERATION ENABLED




Fig. 5-2 STO State Machine

5. STO Safety Function (Optional)

5-4 Safe Operation Sequence Procedure

If deceleration and stop (controlled deceleration and stopping) is required before using the STO function, first perform deceleration and stop operation, then operate the STO function.

1. Drive deceleration and stop operation.
2. In the case of stop state, disable the drive unit.
3. If there is a suspended load, mechanically lock the drive as well.
4. Activate the STO function.

CAUTION

The drive unit cannot generate torque when the STO function operates, so load cannot be maintained.

- When the STO function is operated during driving, the drive unit stops without control.

5-5 Example of Schematic Application




Fig. 5-3 STO Application Example

■ STO 2 Input Feedback

Feedback signals for each STO input can be monitored by two-channel relay output (RET1, RET2).

The status of STO commands can be monitored by output from each relay. (Safety functions can be completely monitored.)

The state of digital input can be read with CANOpen DSP402 (60FDh: Sub-Index 0)

5-6 Function Check

The STO function should be confirmed on first startup after system wiring or parts replacement. Please confirm that STO circuits are functioning correctly every six months.

6. CANOpen Communication

6-1 CANOpen Network Topology




Table 6-1 CANOpen Signals (AGV)

Pin No.	Signal	Description
19	GND_CAN	CANOpen GND
20	CAN_T	120 Ω (CANOpen terminating resistor)
30	CAN_L	CAN_L connection
31	CAN_H	CAN_H connection




Fig. 6-1 CANOpen Wiring

Table 6-2 Status LEDs

Drive State	CANOpen Status	Status 1 LED (Green)	Status 2 LED (Yellow)	LED Display
INIT	Not ready to switch ON Switch ON disabled Ready to switch ON	Alternately "Blink"	Alternately "Blink"	1 Alternately blink 2 Alternately blink
STANDBY	Switched ON	"Blink"	OFF	1 Blink 2 OFF
FAULT	Fault Fault reaction fault	"Blink" Code [x]	"Blink" Code [y]	1 See 8. Diagnostic 2 Table 8-2
RUN	Operation enabled	ON	OFF	1 ON 2 OFF
STOP	Quick Stop Active	ON	ON	1 ON 2 ON
SAFETY	-	OFF	"Blink"	1 OFF 2 Blink

6-2 CANOpen Bitrte and Node ID

Compliance with CiA DS301 v4.02 and DSP402 v2.0 directives.

- CANOpen baudrate: 50K,125K, 250K, 500K, 800K, 1000K (initial setting: 1000Kb)
- Node ID (initial setting: 1)

6. CANOpen Communication

6-3 CANOpen Overview

Features

- TPDO 7, RPDO 7, event timer, access unit 8 bits
- Heartbeat, node guarding
- Baudrate setting: 50K, 125K, 250K, 500K, 800K, 1000K (initial setting: 500K)
- Enable input (standby mode at L-level input, switch ON disabled).
- Node ID setting (default: ID1)
- Parameters are stored in nonvolatile memory (communication + manufacturer name + device profile)
- Load initial CANOpen parameter value from ROM by command.

Compliance with CiA DS301 v4.02 and DSP402 v2.0 directives.

See "CiA DS301 Standards" for additional information.

Reference Materials


- CANOpen User Manual
- CiA 301 (310_1v01010005_cor.pdf)
- CiA 402 (CiA® 402 Draft Standard Proposal.pdf)

(1) Object 6040h: Controlword

This object is used in CiA-402 FSA and CiA-402 modes and for control of manufacturer-specific entities.

Controlword comprise the following bits.

15	11	10	9	8	7	6	5	4	3	2	1	0
ms		r	oms	h	fr	oms		eo	qs	ev	so	
MSB											LSB	
ms: manufacturer-specific			h: halt			qs: quick-stop						
r: reserved			fr: fault reset			ev: enable voltage						
oms: operation mode specific			eo: enable operation			so: switch ON						

Command	Controlword Bits					Transition
	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0	
Shutdown	0	X	1	1	0	2, 6, 8
Switch ON	0	0	1	1	1	3
Switch ON + operation enabled	0	1	1	1	1	3 + 4 Note)
Voltage disabled	0	X	X	0	X	7, 9, 10, 12
Quick stop	0	X	0	1	X	7, 10, 11
Operation disabled	0	0	1	1	1	5
Operation enabled	0	1	1	1	1	4, 16
Fault reset		X	X	X	X	15

Note: After performing switch ON, operation automatically transfers to enabled. This transition interval requires 20 ms or more.

- Bits 9, 6, 5, 4: Operation mode specific
- Bit 8 (halt function): This is an operation mode specific function.
At bit 1 commands are interrupted and drive unit execution halts at the defined option code. After canceling the stop function, the command operation continues.
- Bit 10 (reserved): Please set to 0.
- Bit 11 (manufacturer-specific, warning recognition): Setting to 1 clears the statusword warning bit.
- Bits 12, 13, 14, 15 (manufacturer-specific): Not used

6. CANOpen Communication

(2) Object 6041h: Statusword

This object indicates the current FSA status. There are operation mode and manufacturer-specific bits.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ms		oms		ita	tr	rm	ms	w	sod	qs	ve	f	oe	so	rtso
MSB														LSB	

Bit	Description	M/O
0	Ready to switch ON	M
1	Switched ON	
2	Operation enabled	
3	Fault	
4	Voltage enabled	
5	Quick stop	
6	Switch ON disabled	
7	Warning	O
8	Manufacturer-specific	
9	Remote	M
10	Target reached	
11	Internal limit operation	
12 - 13	Operation mode specific	O
14 - 15	Manufacturer-specific	

- Bit 4 (voltage enabled): 1 indicates that high voltage is supplied to the drive unit.
- Bit 5 (quick stop): 0 indicates that PDS is reacting on a quick stop request.
- Bit 7 (warning): 1 indicates that a warning status occurs.

Note that warnings are not errors or faults (ex: temperature increase, job halt, etc.) The drive unit FSA status therefore does not change.

Warning definitions can be read from the warning parameter object (2003h).

- Bit 10 (target reached): 1 indicates that the PDS reached its set value.

The set value is operation mode specific, and defined in clauses corresponding to some of the profile specifications.

Bit 10 is set to 1 when the operation mode changes.

This bit changes on software updates of target value.

- Bit 11 (internal limit active): 1 indicates that the internal limit functions.
- Bits 12, 13: Operation mode specific (depends on profile set).
- Bit 14 (manufacturer specific: safety): 1 indicates that the drive unit is in safety mode.
- Bit 15 (manufacturer specific: fault): 1 indicates that the drive unit faults.

6. CANOpen Communication

(3) Object 6060h: Mode of Operation

This object can be used to set operation modes and

shows value for required operation modes. Actual PDS operation modes are reflected in the Modes_of_operation_display object.

Bit definitions are as follows.

Bit	Description	Access
0	No mode change/No mode assignment	rw
1	Profile position mode	
2	Velocity mode	
3	Profile velocity mode	
4	Torque profile mode	
5	Reserved	
6	Homing mode	
7	Interpolated position mode	
8	Cyclic synchronous position mode	
9	Cyclic synchronous velocity mode	
10	Cyclic synchronous torque mode	
- x	Manufacturer specifications	

Usable operation modes

- Mode 3: Profile velocity mode
- Mode 1: Analog Mode

6. CANOpen Communication

■ Profile Velocity Mode (3)

In profile velocity mode, profile movement is defined according to velocity and acceleration/deceleration commands.

Start velocity control profile:

- (1) Writing object 6060h = By inputting 3, the drive unit moves to the operation mode of profile velocity mode.
- (2) Operation enabled
- (3) Set acceleration and deceleration in objects 6083/6084h, respectively.
- (4) Operation starts when the target velocity is set in Object 60FFh.

To start operation, clear bit 8 in object 6040h.

The target velocity can be changed during operation. Operation stops when any of the following conditions are satisfied:

- The target velocity is set to zero.
- The Halt command is issued.
- An error occurs.

■ Control Composition in Profile Velocity Mode




Fig. 6-2 Control Composition in Profile Velocity Mode

6. CANOpen Communication




Fig. 6-3 Speed Control Composition

In this mode, the drive unit can follow the set speed.
Please set object 0x6060 (operation mode) to 3.
If the drive unit is in an “operation enabled” state, it is necessary to issue the Halt command, read object 0x6061, and confirm that Mode 3 is accepted.
If the drive unit is not in an “operation enabled” state, there is no need to issue the Halt command (simply set 0x6060 to 3).
If the drive unit is in an “operation enabled” state in profile velocity mode, drive the motor by following the speed setting defined by 0x60FF (rpm). The motor reaches the set value by the acceleration or deceleration defined in 0x6083–0x6084 (rpm/s).

Controlword Bits (Profile Velocity Mode)


15	9	8	7	6	4	3	0
	Halt			Reserved			
MSB				LSB			
Name		Value		Description			
Halt		0		Execute operation			
		1		Stop axle			

6. CANOpen Communication

■ Statusword Bits (Profile Velocity Mode)

15	14	13	12	11	10	9	0
			Speed		Target reached		
MSB				LSB			

Name	Value	Description
Target reached	0	Halt = 0: Target speed not reached Halt = 1: Decelerating
	1	Halt = 0: Target speed reached Halt = 1: Speed zero reached
Speed	0	Non zero speed
	1	Zero speed



6. CANOpen Communication

(4) Object 6061h: Mode of Operation Display

This object defines the actual operation mode.

Object description

Index	Object Code	Data Type	Category
6061h	VAR	Integer 8	Mandatory

Entry description

Subindex	Access	PDO Mapping	Value Range	Default	Unit
00h	ro	YES (default)	-128 - 10	-	-


Bit definitions are as follows.

Bit	Description	Access
0	No mode change/No mode assignment	ro
1	Profile position mode	
2	Velocity mode	
3	Profile velocity mode	
4	Profile torque mode	
5	Reserved	
6	Homing mode	
7	Interpolated position mode	
8	Cyclic synchronous position mode	
9	Cyclic synchronous velocity mode	
10	Cyclic synchronous torque mode	
- x	Manufacturer specifications	

6. CANOpen Communication

6-4 DSP402 State Machine

For additional information, see definitions in “DSP402 v2.0”



The actual status can be read from the statusword. (standard code: defined in CiA DSP402).

State	N°	Description
Not ready to switch ON	S0	Performing self-test during drive unit initialization. Brake output status. Drive unit function is disabled. An internal state, where communication is possible only at the end of this state. Users cannot acquire or monitor this state.
Switch ON disabled	S1	Drive unit initialization completed. Drive unit parameter setup is completed. Drive unit parameters are modifiable. Drive unit function is disabled. Note: Errors are not displayed in this state. Application-side state transition processing is required.

6. CANOpen Communication

State	N°	Description
Ready to switch ON	S2	Drive unit parameters are modifiable. Drive unit function is disabled.
Switched ON	S3	Power amp is standby. Drive unit parameters are modifiable. Drive unit function is disabled.
Operation enabled	S4	No faults are detected. Drive unit functions are enabled and power is supplied to the motor. Drive unit parameters are modifiable. The brake is automatically released at the timing set by brake parameters.
Quick stop active	S7	Drive unit parameters are modifiable. Activating the quick-stop function. Drive unit functions are enabled and power is supplied to the motor. The motor is stopped or is stopping by the quick stop active. Motor deceleration is completed and the drive unit is stopping. If the quick stop active code (object 0X605A) is 0, the state of the drive is switch ON disabled.
Fault reaction active	SE	Drive unit parameters is modifiable. Drive unit fault occurred. Performing fault reaction. Drive unit function is disabled. Users cannot acquire this status. This status automatically transfers to the fault status.
Fault	SF	Drive unit parameters are modifiable. Drive unit fault occurred. Drive unit function is disabled.

6-5 CANOpen Run Sequence

- (1) Power switch ON
- (2) Verify LED status 1, 2 initial state (INIT mode)
- (3) Configure profile velocity: 0x6060 → 0x03
- (4) **Ready to switch ON** setting: Controlword write 0x6040 → 0x06
- (5) **Switched ON** setting: Controlword write 0x6040 → 0x07
- (6) Verify whether smartris drive state is switched ON: Statusword read 0x6041 → 0x23
- (7) **Operation enabled** setting: Controlword write 0x6040 → 0x0F
- (8) Verify whether LED status is enabled
Verify whether smartris drive state is enabled: Statusword read 0x6041 → 0x27
Verify brake release.
- (9) Read speed command set value 0x60FF → 0x03e8 (Ex: set 1000 r/min)
- (10) If motor revolutions are confirmed, verify motor speed (after acceleration is complete):
Read 0x606C → 0x03e8 (Ex: 1000 r/min)

Note: The motor immediately stops upon issuance of the STO safety command (**SAFETY**).

Commands being executed are immediately halted upon issuance of a stop command (**STOP**).

Commands being executed are immediately halted when a fault (**FAULT**); see 8. Diagnostic Table 8-2) occurs.

6. CANOpen Communication




Fig. 6-4 CANOpen Run Sequence

6. CANOpen Communication

6-6 Speed Polarity

Speed set value can be inverted by a CANOpen mode (either clockwise or counterclockwise). This object affects the signs on "Position_demand_value" and "Velocity_demand_value."

Object description

Index	EDS Name	Object Code	Data Type	Category
607Eh	Polarity	VAR	Unsigned 8	Mandatory

Entry description

Subindex	C Name	Description	Access	PDO Mapping	Value Range	Default
0	p402 polarity	Polarity	rw	None	0 - 192	00h

Bit

7	6	5	4	3	2	1	0
Positional polarity	Speed polarity	Reserved region (0)					
MSB				LSB			

The following value definitions are valid:

- Bit value = 0: +1 times the required value
- Bit value = 1: -1 times the required value

6-7 Store and Restore

The CiA CANOpen protocol specifications define objects that store and restore parameters.

- Object 1010h: Store parameter
- Object 1011h: Restore parameter

In order to save all parameters, the master writes in the SDO 1010h index the value "save" to one of the subentries of the object.

By this processing, corresponding parameter is written in nonvolatile memory.

Parameters are automatically loaded into the object dictionary after an NMT reset node or NMT reset communication.

The following objects are modified by writing to object 1010h:2h (communication parameters) and saved in EEPROM:

- 1000h: Device type
- 1001h: Error register
- 1002h: Manufacturer-specific status register
- 1003h: Predefined error field (history list)
- 1005h: COB-ID Sync
- 100Ch: Guard time
- 100Dh: Lifetime factor
- 1014h: COB-ID EMCY
- 1017h: Producer heartbeat time

6. CANOpen Communication

- 1018h: Identity Object
- 1029h: Error behavior
- 1400h: RxPD01 parameter
- 1401h: RxPD02 parameter
- 1402h: RxPD03 parameter
- 1403h: RxPD04 parameter
- 1600h: RxPD01 mapping
- 1601h: RxPD02 mapping
- 1602h: RxPD03 mapping
- 1603h: RxPD04 mapping
- 1800h: TxPD01 parameter
- 1801h: TxPD02 parameter
- 1802h: TxPD03 parameter
- 1803h: TxPD04 parameter
- 1A00h: TxPD01 mapping
- 1A01h: TxPD02 mapping
- 1A02h: TxPD03 mapping
- 1A03h: TxPD04 mapping

The following objects are modified by writing to object 1010h:3h (application parameters) and saved in EEPROM:

- 6073h: Peak current
- 607Eh: Polarity Note
- 607Fh: Maximum profile velocity
- 6080h: Maximum motor speed
- 6083h: Acceleration profile Note
- 6084h: Deceleration profile Note
- 6096H: Velocity factor
- 6097h: Acceleration factor
- 60C5h: Maximum acceleration
- 60C6h: Maximum deceleration

The following objects are modified by writing to object 1010h:4h (manufacturer settings parameters) and saved in EEPROM:

- 2000h: ID Node
- 2001h: Baudrate
- 3002h: Brake parameters Note
- 3007h: : Dynamic Brake parameters Note
- 3200h: PID current Note
- 3201h: PID velocity Note
- 3202h: PID positioner Note
- 3203h: PID decoupling Note


Note: Parameters modifiable in real time that will be lost if the drive unit is shut off.

6. CANOpen Communication

All parameters can be stored in EEPROM. Modification requests are not accepted until a power reset or until the CANOpen "RESET COMM (NMT)" message is sent to the drive unit.
Manufacturer setting parameters are stored in a protected EEPROM called "Golden Image."
You can use the restore parameter 0x1011 to return EEPROM parameters to factory parameters.

In order to avoid the restoring of default parameters by mistake, the master sends the SDO 1011h and writes the signature "load" to one of sub-index.

■ **Function Mode for Restoring Factory Parameters:**



7. Measurement Unit Conversion

Parameters are used in various applications.
To more easily set parameters in different applications, you can use the measurement unit conversion module to convert user parameters into units used within the drive unit.




Fig. 7-1 Factor Groups

Factor group objects convert internal position value, speed value, and acceleration/deceleration value into user-defined units.
Internal position value are entered as increments and depend on the resolution of the feedback used.
User-defined units depend on the encoder resolution and the mounted linear moving device (the linear shaft).




Fig. 7-2 Factor Group Units

All parameters are recorded by using internal units.
Parameters can be converted using factor-group values on a per-user basis.

Default is as follows.

Object	Name	User Units	Description
Length	Position unit	Inc	Increment/gear ratio
Speed	Speed unit	Inc/s	Increment/s
Acceleration	Acceleration unit	Inc/s ²	Increment/s/s

Factors defined in factor groups set relations between internal units (increments) and physical units.
User units are defined as [uu] and internal units are defined as [iu].

7. Measurement Unit Conversion

7-1 Conversion Parameters for Measurement Unit

The factor is the result calculated from numerator and denominator parameters.

Index	Name	Object Code	Data Type	Attribute	Remarks
608Fh	Encoder resolution (position)	ARRAY	Unsigned 32	rw	Unused
6090h	Encoder resolution (velocity)				
6091h	Gear ratio				
6092h	Feed constant				
6096h	Velocity factor				
6097h	Acceleration factor				Used

■ Object 6096h: Velocity Factor

This object can be used to match velocity units with user-defined velocity units.

Object description:

Index	EDS Name	Object Code	Data Type	Category
6096h	Velocity factor	ARRAY	Unsigned 32	Mandatory

Entry description:

Subindex	Description	Access	PDO Mapping	Data Type	Default
0	Highest subindex	ro	None	Unsigned 32	2
1	Numerator	rw			1
2	Denominator	rw			1

Velocity factor numerators and denominators are input separately.

Velocity factor = (numerator / denominator)

Default for user units [inc/s] is 1 for both numerator and denominator.

Velocity [iu] = velocity [uu] × (60 / resolution) × (numerator / denominator)

Resolution is one rotation of the encoder, or a measurement segment at a 1 in/mm linear scale, or the number of units.

e.g.: Velocity settings are defined as revolutions/min (rpm).

Velocity [inc/s] = velocity [rpm] × (60 / resolution) × (numerator / denominator)

If the encoder resolution is 2^{13} bits = 16,384, the numerator is 16,384 and the denominator is 60.

Factor groups are used for the following objects:

- 60FFh: Target velocity
- 606Dh: Velocity window
- 606Fh: Velocity threshold

7. Measurement Unit Conversion

■ Object 6097h: Acceleration Factor

This object can be used to match acceleration units with user-defined acceleration units.

Object description

Index	EDS Name	Object Code	Data Type	Category
6097h	Acceleration factor	Array	Unsigned 32	Mandatory

Entry description

Subindex	Description	Access	PDO Mapping	Value Range	Default
0	Highest subindex	ro	None	Unsigned 32	2
1	Numerator	rw			1
2	Denominator	rw			1

Acceleration factor numerators and denominators are input separately.

Acceleration factor = (numerator / denominator)

Default for user units [inc/s²] is 1 for both numerator and denominator.

Acceleration [iu] = velocity [uu] × (60 / resolution) × (numerator / denominator)

Resolution is one rotation of the encoder, or a measurement segment at a 1 in/mm linear scale, or the number of units.

e.g.: Acceleration settings are defined as revolutions/min (rpm).


Acceleration [inc/s²] = acceleration [rpm/s] × (60 / resolution) × (numerator / denominator)

If the encoder resolution is 2¹³ bits = 16,384, the numerator is 16,384 and the denominator is 60.

Factor groups are used for the following objects:

- 6083h: Profile acceleration
- 6084h: Profile deceleration
- 60C5h: Maximum acceleration
- 60C6h: Maximum deceleration

8-1 Diagnostic



- LEDs 1 and 2 on the right side of the main unit show the drive status; the green LED shows status 1, and the yellow LED shows status 2

Table 8-1 Status LEDs


Drive State	CANOpen Status	Status 1 LED (Green)	Status 2 LED (Yellow)	LED Display
INIT	Not ready to switch ON Switch ON disabled Ready to switch ON	Alternately "Blink"	Alternately "Blink"	1 Alternately blink 2 Alternately blink
STANDBY	Switched ON	"Blink"	OFF	1 Blink 50% 2 OFF
FAULT	Fault Fault reaction fault	"Blink" Code [x]	"Blink" Code [y]	1 See Fig. 8-2 2
RUN	Operation enabled	ON	OFF	1 ON 2 OFF
STOP	Quick stop active	ON	ON	1 ON 2 ON
SAFETY	-	OFF	"Blink"	1 OFF 2 Blink

8. Diagnostic

Table 8-2 List of Alarms

Category	Alarm	Status 1 LED (Green)	Status 2 LED (Yellow)	Alarm Description
		☼ Code [x]	☼ Code [y]	
A Temperature	Motor over temperature	1	10	Motor temperature exceeds the temperature setting. Operation is impossible due to high motor temperature.
	Heat sink over temperature		1	Heat sink temperature exceeds the temperature setting. Operation is impossible due to high heat sink temperature.
	Heat sink temperature out of range		3	Heat sink temperature is beyond range of the temperature sensor. Temperature sensor malfunction
	PCB over temperature		5	PCB temperature exceeds the temperature setting. Operation is impossible due to high PCB temperature.
	PCB temperature out of range		6	PCB temperature is beyond range of the temperature sensor. Temperature sensor malfunction
B Feedback	Resolver	2	10	Check resolver connector and wiring
	Resolver initialization		4	Resolver initialization error
	Absolute encoder		6	Absolute encoder fault
	Hall sensor		7	Hall sensor fault
	Hall sensor gap		8	
C Current	Current sensor offset	3	10	Current sensor offset is out of range
	Overcurrent		1	Motor overcurrent Check motor wiring for shorts
D Voltage	Undervoltage	4	1	DC bus voltage is below set value Check +/- power terminal voltages
	Overvoltage		2	DC bus voltage exceeds set value Check +/- power terminal voltages
E Functionality	Speed fault	5	10	Large error between commanded speed and actual speed
	Overload protection (I ² T)		2	Motor overload protection (I ² T)
	Hardware		3	Hardware fault
F Communication	EEPROM	6	1	Erroneous parameter stored in EEPROM
	CanOpen		2	CanOpen communication fault
	Absolute fault		3	Internal communication fault
	Parameter initialization		4	Parameter initialization fault
	Profile		5	Profile setting fault
G, H, L Programming	Program fault	7	×	Program code fault
		8		
		9		

9-1 Connections Diagram



Note: Also see “1-5. Installation and Terminal Connections” regarding cable wiring.
The figure above is a block diagram for easier understanding of wiring.

Table 9-1 Power Connections

Pin No.	Signal Name	Description	Color (Example)
+	+VBUS	Connection to +VBUS (+48 Vdc)	Red
—	-VBUS	Connection to -VBUS	Black

Table 9-2 Motor Connections

Pin No.	Signal Name	Description	Color (Example)
U	phase U	Motor phase U	Black
V	phase V	Motor phase V	White
W	phase W	Motor phase W	Red

Table 9-3 Brake Connections

Pin No.	Signal Name	Description	Color (Example)
+	+VBUS	Connection to “Brake +” and +VBUS	Orange
B	BRAKE	Connection to “Brake –” and B	Gray

9. Connections

9-2 Nameplate and Codes

■ Nameplate






Fig. 9-1 Nameplate of smartris

■ Nomenclature





10. Cables (Optional)




Pin No.	Color (example)	Pin No.	Color (example)	Pin No.	Color (example)
1	Black	13	Brown-green	25	Blue
2	Pink	14	Brown	26	White-blue
3	White-pink	15	Yellow	27	Gray-blue
4	Yellow-pink	16	Purple	28	Green-blue
5	Pink-green	17	White-yellow	29	Yellow-blue
6	Pink-brown	18	White-black	30	Green
7	Gray-brown	19	Brown-black	31	White
8	Gray-green	20	White-green	32	NC Note
9	White-gray	21	NC Note	33	
10	Gray	22	Brown-red	34	Green-red
11	White-red	23	Yellow-brown	35	Yellow-black
12	Yellow-red	24	Red	Shield	External sheath

Note: No connection



Pin 1

776273-1 (14 pins)	Signal	Color	M23 (12 pins)
1	S2	White	1
2	S1	Green	2
7	S3	Yellow	3
-	NC	-	4
-	NC	-	5
6	S4	Brown	6
3	R1	Red	7
5	Shield	-	8
12	NTC1a	Pink	9
13	NTC1b	Gray	10
8	R2	Blue	11
-	NC	-	12




Connector pin topology

Note: Twisted pair (white-brown) (green-yellow) (gray-pink) (blue-red)

10. Cables (Optional)

X2— Absolute encoder cable: CBF6C01SS0



Note: Twisted pair (green–brown) (blue–violet) (red–black) (gray–pink) (brown 0.5–white 0.5)

11. Warranty

The scope of warranty of our delivered products is limited only to what we manufactured.

Warranty (period and description)

Period	The warranty period applies only to new products and represents 18 months after the shipment or 12 months after the actual operation, whichever is shorter.
Description	<p>If the product failed within the warranty period, in the case where mounting is done properly, connection and maintenance & administration are followed according to the maintenance manual, and the product is properly run based on the specification on the catalog or under conditions agreed between us, we will repair or provide an alternative product at our discretion for free of charge, except the exclusions below.</p> <p>However, as far as the product is connected with customers' other devices, we will not indemnify those expenses on dismounting from/mounting on the devices, etc. and other associated construction expenses, transportation expenses and opportunity loss and operation loss the customers suffered from, and other indirect damages.</p>
Exclusion from the warranty	<p>The following items will be excluded from the warranty:</p> <ol style="list-style-type: none">1. A breakdown resulting from defects in the mounting of the product and connection with other devices, etc.2. A breakdown resulting from insufficient maintenance & administration and improper handling of the product, including a case that the product is not stored according to our defined storage manual.3. A breakdown resulting from operation which does not fall within our specification and other operation conditions and use status we hardly can know or a failure caused by the use of lubricant which we do not recommended.4. A breakdown resulting from defects, special specification, etc of device prepared and connected by customer.5. A breakdown resulting from modification or reconstruction of the product.6. A secondary breakdown occurring in our product due to defects in sequence circuits.7. A breakdown resulting from defects in parts supplied or specified by customers.8. A breakdown caused by inevitable force including earthquake, fire, flood disaster, salt damage, gas damage, and lightning strike, etc.9. Warranty of natural wear and tear, abrasion, and deterioration of consumable parts such as Aluminum electrolytic capacitor etc. under normal usage.10. A breakdown caused for reasons not attributable to each of the above item.

【MEMO】

Worldwide Locations

U.S.A

Sumitomo Machinery Corporation of America (SMA)
4200 Holland Blvd. Chesapeake, VA 23323, U.S.A.
TEL (1)957-485-3355 FAX (1)757-485-7490

Canada

SM Cyclo of Canada, Ltd. (SMC)
1453 Cornwall Road, Oakville, Canada ON L6J 7T5
TEL (1)905-469-1050 FAX (1)905-469-1055

Mexico

SM Cyclo de Mexico, S.A. de C.V. (SMME)
Av. Desarrollo 541, Col. Finsa, Guadalupe, Nuevo León, México, CP67132
TEL (52)81-8144-5130 FAX (52)81-8144-5130

Brazil

Sumitomo Industrias Pesadas do Brasil Ltda. (SHIB)
Rodovia do Acucar (SP-075) Km 26
Itu, Sao Paulo, Brasil
TEL (55)11-4886-1000 FAX (55)11-4886-1000

Chile

SM-Cyclo de Chile Ltda. (SMCH)
Camino Lo Echevers 550, Bodegas 5 y 6, Quilicura, Región Metropolitana, Chile
TEL (56)2-892-7000 FAX (56)2-892-7001

Argentina

SM-Cyclo de Argentina S.A. (SMAR)
Ing Delpini 2230, B1615KGB Grand Bourg, Malvinas Argentinas, Buenos Aires, Argentina
TEL (54)3327-45-4095 FAX (54)3327-45-4099

Guatemala

SM Cyclo de Guatemala Ensambladora, Ltda. (SMGT)
Parque Industrial Unisur, 0 Calle B 19-50 Zona 3, Bodega D-1 Delta Bárcenas en Villa Nueva, Guatemala
TEL (502)6648-0500 FAX (502)6631-9171

Colombia

SM Cyclo Colombia, S.A.S. (SMCO)
Parque Industrial Celta, Km 7.0 Autopista Medellín, Costado Occidental, Funza, Cundinamarca, Colombia
TEL (57)1-826-9766

Peru

SM Cyclo de Perú, S.A.C (SMPE)
Jr. Monte Rosa 255, Oficina 702, Lima, Santiago de Surco, Perú
TEL (51)1-713-0342 FAX (51)1-715-0223

Germany

Sumitomo (SHI) Cyclo Drive Germany GmbH (SCG)
Cyclostraße 92, 85229 Markt Indersdorf, Germany
TEL (49)8136-66-0 FAX (49)8136-7771

Austria

Sumitomo (SHI) Cyclo Drive Germany GmbH (SCG)
SCG Branch Austria Office
Gruentalstraße 30A, 4020 Linz, Austria
TEL (43)732-330958 FAX (43)732-331978

Belgium

Hansen Industrial Transmissions NV (HIT)
Leonardo da Vincilaan 1, Edegem, Belgium
TEL (32)34-50-12-11 FAX (32)34-50-12-20

France

SM-Cyclo France SAS (SMFR)
8 Avenue Christian Doppler, 77700 Serris, France
TEL (33)9448-05389 FAX (33)164171718

Italy

SM-Cyclo Italy Srl (SMIT)
Via dell' Artigianato 23, 20010 Cornaredo (MI), Italy
TEL (39)293-481101 FAX (39)293-481103

Spain

SM-Cyclo Iberia, S.L.U. (SMIB)
C/Gran Via Nº 63 Bis, Planta 1, Departamento 1B
48011 Bilbao–Vizcaya, Spain
TEL (34)9448-05389 FAX (34)9448-01550

United Kingdom

SM-Cyclo UK Ltd. (SMUK)
Unit 29, Bergen Way, Sutton Fields Industrial Estate, Kingston upon Hull, HU7 0YQ, East Yorkshire, United Kingdom
TEL (44)1482-790340 FAX (44)1482-790321

Turkey

SM Cyclo Turkey Güç Aktarım Sis. Tic. Ltd. Sti. (SMTR)
Barbaros Mh. Çiğdem Sk. Ağaoglu, Office Mrk. No:1 Kat:4 D.18 Ataşehir, Istanbul, Turkey
TEL (90)216-250-6069 FAX (90)216-250-5556

India

Sumi-Cyclo Drive India Private Limited (SDI)
Gat No. 186, Raisoni Industrial Park, Alandi Markal Road, Fulgaon-Pune, Maharashtra, India
TEL (91)96-0774-5353

China

Sumitomo (SHI) Cyclo Drive Shanghai, Ltd. (SCS)
11F, SMEG Plaza, No. 1386 Hongqiao Road, Changning District, Shanghai, China 200336
TEL (86)21-3462-7877 FAX (86)21-3462-7922

Hong Kong

SM-Cyclo of Hong Kong Co., Ltd. (SMHK)
Room 19, 28th Floor, Metropole Square, No.2 On Yiu Street, Shatin, New Territories, Hong Kong
TEL (852)2460-1881 FAX (852)2460-1882

Korea

Sumitomo (SHI) Cyclo Drive Korea, Ltd. (SCK)
Room #913, Royal Bldg, Saemun-ro 5 gil 19, Jongro-gu, Seoul, Korea 03173
TEL (82)2-730-0151 FAX (82)2-730-0156

Taiwan

Tatung SM-Cyclo Co., Ltd. (TSC)
22 Chungshan N. Road 3rd., Sec. Taipei, Taiwan 104, R.O.C.
TEL (886)2-2595-7275 FAX (886)2-2595-5594

Singapore

Sumitomo (SHI) Cyclo Drive Asia Pacific Pte. Ltd. (SCA)
15 Kwong Min Road, Singapore 628718
TEL (65)6591-7800 FAX (65)6863-4238

Philippines

Sumitomo (SHI) Cyclo Drive Asia Pacific Pte. Ltd. Philippines Branch Office (SMPH)
C4 & C5 Buildings Granville Industrial Complex, Carmona, Cavite 4116, Philippines
TEL (63)2-584-4921 FAX (63)2-584-4922

Vietnam

SM-Cyclo (Vietnam) Co., Ltd. (SMVN)
Factory 2B, Lot K1-2-5, Road No. 2-3-5A, Le Minh Xuan Industrial Park, Binh Chanh Dist., HCMC, Vietnam
TEL (84)8-3766-3709 FAX (84)8-3766-3710

Malaysia

SM-Cyclo (Malaysia) Sdn. Bhd. (SMMA)
No.7C, Jalan Anggerik Mokara 31/56, Kota Kemuning, Seksyen 31, 40460 Shah Alam, Selangor Darul Ehsan, Malaysia
TEL (60)3-5121-0455 FAX (60)3-5121-0578

Indonesia

PT. SM-Cyclo Indonesia (SMID)
Jalan Sungkai Blok F 25 No. 09 K, Delta Silicon III, Lippo Cikarang, Bekasi 17530, Indonesia
TEL (62)21-2961-2100 FAX (62)21-2961-2211

Thailand

SM-Cyclo (Thailand) Co., Ltd. (SMTH)
195 Empire Tower, Unit 2103-4, 21st Floor, South Sathorn Road, Yannawa, Sathorn, Bangkok 10120, Thailand
TEL (66)2670-0998 FAX (66)2670-0999

Australia

Sumitomo (SHI) Hansen Australia Pty. Ltd. (SHAU)
181 Power St, Glendenning, NSW 2761, Australia
TEL (61)2-9208-3000 FAX (61)2-9208-3050

Japan

Sumitomo Heavy Industries, Ltd. (SHI)
ThinkPark Tower, 1-1 Osaki 2-chome, Shinagawa-ku, Tokyo 141-6025, Japan
TEL (81)3-6737-2511 FAX (81)3-6866-5160



Sumitomo Heavy Industries, Ltd.

Power Transmission & Controls Group

Headquarter ThinkPark Tower, 1-1 Osaki 2-chome, Shinagawa-ku, Tokyo 141-6025, Japan

Specifications, dimensions, and other items are subject to change without prior notice.

No.DM1802E-1.0

EA12 Printed 2021.02